

## FAGOR HTT 102 UPGRADING METHOD

At first, please prepare a USB Disk(or say USB stick).



Then do as below to complete the upgrading:

- 1) Format the file system of the USB Disk into [FAT32](#) format,if it is not FAT32;
- 2) copy the upgrade file([xxx.img](#)) to the root directory of the USB Disk;If there are other files in the USB Disk, please move them to your PC's hard-disk 1st;
- 3) power off the equipment;
- 3) plug in the USB Disk into the USB interface on the rear panel of the equipment;
- 4) power on the equipment;
- 5) Please wait till LCD display characters;
- 6) If you see LCD menu is appearing, please power off equipment;
- 7) Please unplug out the USB Disk.
- 8) Power on the equipment again.